

Swing safety couplings DN 6, acc. ISO 6150 C

Art. No. 141628 to 141646

P 5-129 e

»R-SC/K« series

Swing safety coupling with free passage.

The plug-in nipple is inserted into the coupling body and rotated by an approx. 90° motion to make the connection.

As soon as the "red ring" clicks into the intended slot then a secure connection has been made.

To release the connection again, the "red ring" must be pulled out and the plug-in nipple is swivelled to the stopper into the starting position. Venting is done during uncoupling through a vent hole on the back side of the coupling.

This coupling meets ISO standard DIN EN ISO 4414, EN 983.

Areas of application: Pneumatic system, machine and plant engineering, measurement, monitoring and control systems, manufacturing industry, workshops, automotive, mining.

Operating pressure max. 25 bar / max. 16 bar when attaching / detaching

Technical vacuum 100 mbar
Temperature range -20 °C to 100 °C
Flow rate 820 l/min (air)

Flow rate measurement at 6 bar and $\Delta p = 0.5$ bar Medium Compressed air, gases Housing Steel, QPQ treated

Sleeve Die-cast zinc, nickel-plated, red rubber coated

Threaded piece Galvanised steel

Sealant NBR

Lubrication Silicone-free

Corrosion resistance 72 h salt spray test according to DIN 50021 SS

Necessary coupling force of the plug 10 N (at 6 bar)
Plug profile acc. ISO 6150 C



Swing safety coupling DN 6, acc. ISO 6150 C, male				
Art. No.	Type No.	Connection	Length	a/f
	.,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,		mm mm	mm
141628	423.11-SCH	G 1/4 ET	59.0	19
141629	423.12-SCH	G 3/8 ET	59.0	19
141630	423.13-SCH	G 1/2 ET	61.0	22
141631	423.11-SCH-NPT	NPT 1/4 ET	63.0	19
141632	423.12-SCH-NPT	NPT 3/8 ET	63.0	20
141633	423.13-SCH-NPT	NPT 1/2 ET	68.0	20

Swing safety coupling DN 6, acc. ISO 6150 C, female					
Art. No.	Type No.	Connection	Length	a/f	
Art. No.		Connection	mm mm	mm	
141622	423.01-SCH	G 1/4 IT	56.0	19	
141623	423.02-SCH	G 3/8 IT	58.0	19	
141624	423.03-SCH	G 1/2 IT	61.0	24	
141625	423.01-SCH-NPT	NPT 1/4 IT	56.0	19	
141626	423.02-SCH-NPT	NPT 3/8 IT	79.0	27	
141627	423.03-SCH-NPT	NPT 1/2 IT	65.0	24	

Edition 07/2018

P 5-129 e


Swing safety couplings DN 6, acc. ISO 6150 C


Art. No. 141628 to 141646



Swing safety coupling DN 6, acc. ISO 6150 C, with hose stem					
Art. No.	Type No.	Connection	Length	a/f	
AIL NO.	Type No.	Connection	mm	mm	
141634	423.21-SCH	Stem, I.D. 6	68.0	20	
141635	423.22-SCH	Stem, I.D. 8	68.0	19	
141636	423.24-SCH	Stem, I.D. 10	68.0	20	

Swing safety coupling DN 6, acc. ISO 6150 C, with hose connector					
Art. No.	Type No.	Connection	Length mm	a/f mm	
141637	423.32-SCH	Hose connection 6.5x10	63.0	20	
141638	423.34-SCH	Hose connection 8x12	66.0	19	








423.12-SCH




423.02-SCH





423.21-SCH





423.32-SCH

Swing safety couplings DN 6, acc. ISO 6150 C


Art. No. 141628 to 141646

P 5-129 e

Stem for couplings DN 6, ISO 6150 C, steel, QPQ treated					
Art. No.	Type No.	Description	Length mm		
141647	423.71	Stem, I.D. 6	55.0		
141648	423.72	Stem, I.D. 8	55.0		
141649	423.74	Stem, I.D. 10	55.0		
141650	423.75	Stem, I.D. 13	55.0		


Plug for couplings DN 6, ISO 6150 C, steel, QPQ treated, male					
Art. No.	Type No.	Description	Length	a/f	
Art. NO.	Type No.	Description	mm	mm	
141639	423.60	Plug, G 1/8 ET	46.0	14	
141640	423.61	Plug, G 1/4 ET	46.0	14	
141641	423.62	Plug, G 3/8 ET	49.0	17	
141642	423.61-NPT	Plug, NPT 1/4 ET	50.0	14	
141643	423.62-NPT	Plug, NPT 3/8 ET	53.0	17	

Plug for couplings DN 6, ISO 6150 C, steel, QPQ treated, female					
Art. No.	Type No.	Description	Length	a/f	
ALL. NO.	Type No.	Description	mm	mm	
141644	423.50	Plug, G 1/8 IT	46.0	14	
141645	423.51	Plug, G 1/4 IT	47.0	17	
141646	423.51-NPT	Plug, NPT 1/4 IT	48.0	17	






423.74





423.62

Edition 07/2018





423.51

P 5-129 e

Swing safety couplings DN 6, acc. ISO 6150 C

Art. No. 141628 to 141646



Installation location

The installation location of the quick-connect coupling must be selected so that the health of the person operating it cannot be harmed by sources of danger in the immediate surroundings, e.g. from slipping, jamming, contaminating or burning.

Low pressure applications

Threads for low-pressure applications are, if seriesrelated no corresponding coatings or sealing rings are present, to be provided with suitable sealing materials, such as a PTFE belt or liquid sealing agent. Here the resistance to the flowing medium must be paid attention to.

Service manual

Quick-connect couplings are predominantly maintenance-free, if used in standard applications and handled carefully. The selection of the quick-connect coupling must be compatible with the intended purpose of use and material. Depending on the operating conditions it is recommended to provide the following points during maintenance:

External visual inspection with dirt in the functioning area of coupling and plug (seal area, control elements) these must be cleaned. The following distinguishing symptoms require replacement of the corresponding parts: Torn, damaged, heavily damaged or corroded parts, leaks on coupling and / or plug parts.

Function test under maximum Max. operating pressure can be used to test the quick-connect coupling for possible malfunctions and leaks. During the testing and operating phase it must be ensured that the operating personnel work protected.


Replacement intervals for quick-connect couplings must, if available, be adapted to the state or technical standards. However, also operating experiential values, which result from the required operational safety and the conditions of use, such as downtimes, coupling frequency, Max. operating pressure and properties of the medium, are critical for establishing the replacement intervals.

Pulsating tool

When using pulsating tools it is recommended to observe the standard ISO 6150, § 7.1. It recommends installing a minimum 300 mm long, flexible hose between the pulsating tool and the quick-connect coupling. The oscillating forces are taken by the hose piece and thus increase the service life of the quick-connect coupling. No warranty can be made for couplings mounted directly on pulsating tools.

Flow direction

The recommended flow direction is from the coupling to the plug if nothing else is specified in the technical data sheet.



Application with hoses

When using hoses the permissible Max. operating pressure and the working temperature must absolutely be observed and suitable hose connections must be seen to.